



Yealink Cordless Handsets: How To Access Voicemail

Voicemail feature ensures you will never miss any important messages recorded to your UNIVERGE BLUE® CONNECT extension number when someone leaves an important message for you.

The desktop phone light alert will alert you to the number of unread voicemails, and the message key LED flashes.

Read our [Supported/Unsupported Devices](#) list article for more information, to investigate any featured utilities by user guide settings shared by and tested with your UNIVERGE BLUE® CONNECT account.

Note: The voicemail feature is not available on all services if you reassigned a DID under new settings via \$cpanel. Contact your system administrator for more information.

You can leave a voicemail to someone else when they are busy or cannot answer the call. Follow the voice prompts from the system server to leave a voicemail, and then hang up.

To configure the voicemail access PIN number via the handset:

1. Press **OK** to enter the main menu.
2. Select *Voicemail > Set Voice Mail*. The screen will display the lines assigned to the handset as incoming lines and outgoing lines simultaneously, and the number of voicemails for each line.
3. Press the **Left** or **Right** key to highlight the desired line, and then press the **Select** soft key.
4. Press the **Up** or **Down** key to select **Enabled** from the **Status** field.
5. Enter the voicemail access code in the **Number** field.
6. Press the **OK** soft key to accept the change or the **Back** soft key to cancel.

You can configure fast access to connect straight to the voicemails of the desired line by long pressing the digit key 1 without having to scroll through the menu when the handset is idle.

1. Press **OK** to enter the main menu.
2. Select *Voicemail > Set Key 1*. The screen displays the lines assigned to the handset as incoming lines and outgoing lines simultaneously.
3. Press the **Up** or **Down** key to highlight the desired line and press the **Select** soft key. The radio box of the selected line will be marked.

To listen to the voicemail using the menu via the handset:

1. Press **OK** to enter the main menu.
2. Select *Voicemail > Play Message*. The screen displays the lines assigned to the handset as incoming lines and outgoing lines simultaneously, and the number of voicemails for each line.
3. Press the **Up** or **Down** key to highlight the desired line, and then press the **Select** soft key. The handset will dial out the voicemail access code using the selected line automatically.
4. Follow the voice prompt from the system server to listen to your voicemails.

To listen to the voicemail via fast access via the handset:

1. Long press *Voicemail > Key 1* when the handset is idle. The handset will automatically dial out the voicemail access code using the line you selected when configuring fast access for voicemail.
2. Follow the voice prompt from the system server to listen to your voicemails. You can also listen to the voicemail by pressing the **Message** key to enter the Messages & Calls screen. Select the desired line and press the **Select** soft key.

Note: before listening to the voicemails, make sure the voicemail PIN number has been configured. When all new voicemails are retrieved, the icon will disappear from the screen by device settings.

Important: if you need assistance updating your Voicemail PIN code, contact our Tech Support Team, or your administrator.

Article Information

Article ID: 13871

Last updated on: 05/22/2023 08:04 AM

Product: [UNIVERGE BLUE® CONNECT](#)

Related Articles

[Voicemail Transcription](#)

[UNIVERGE BLUE® CONNECT Desktop App: Checking Voicemail](#)

[Voicemail Types On UNIVERGE BLUE® CONNECT](#)

[Yealink Cordless Handsets: How To Place Calls \(Internal And External\)](#)

[UNIVERGE BLUE® CONNECT Mobile App: Checking New Voicemail](#)